


### RMDS25 25lb. Mini Digital Scale


 REQUIRES ONE CR2032 LITHIUM COIN BATTERY

**TURN ON & OFF** Press and hold "ON/OFF/TARE" button.

**TARE WEIGHT** Hang the empty container that fish will be weighed in on hook. Press "ON/OFF/TARE" button to reset the scale to zero. Add fish to the container and weigh. To reset, take the container and fish off hook and press "ON/OFF/TARE" button to go back to zero without tare.

**CHANGING LBS TO KG** Press and hold the "ON/OFF/TARE" button until the numbers are blinking, press the "ON/OFF/TARE" button again to select lbs or kg. Once selected, wait for numbers to flash.

Now the scale is ready to use.



Remove the battery screw in the back of scale before trying to open the side battery compartment. Reinstall the screw after replacing battery and closing the side compartment.

### RMDS50 50lb. Mini Digital Scale

 REQUIRES ONE 9V BATTERY

**TURN ON & OFF** Press and hold "ON/OFF/TARE" button.

**AUTO SHUTOFF** After 4 minutes the scale will automatically shut off.

**TARE WEIGHT** Hang the empty container that fish will be weighed in on hook. Press "ON/OFF/TARE" button to reset the scale to zero. Add fish to the container and weigh. To reset, take the container and fish off hook and press "ON/OFF/TARE" button to go back to zero without tare.

**CHANGING LBS TO KG** Press the "ON/OFF/TARE" button to turn on scale, while the numbers are blinking press the "ON/OFF/TARE" button again to select lbs or kg. Once selected, wait for numbers to flash. Now the scale is ready to use.

